


SYM	PART#	DESCRIPTION	QTY
1	AB1434(9)HD	URM CROSS ARM, HDG	1
2	AB1430HD	URM LH ARM, HDG	2
3	AB1431HD	URM RH ARM, HDG	2
4	AB1119BHD	6' BALLAST ANGLE, HDG	4
5	as req'd	MAST (O.D. & Length as req'd)	1
6	H1-0375-150	3/8"x1-1/2" BOLT GR.5, Z/P	2
7	H1-0375-200GR5	3/8"x2" BOLT GR.5, Z/P	2
8	H1-0375-100	3/8"x1" BOLT GR.5, Z/P	8
9	H2-0375LW	3/8" SPLIT LOCKWASHER, Z/P	12
10	H2-0375HN	3/8" NUT, Z/P	12
11	H2-0500HN	1/2" NUT, Z/P (used as spacer)	2
12	H1-0750-200	3/4" x 2" BOLT GR.5, Z/P	4
13	H4-0750LW	3/4" SPLIT LOCKWASHER, Z/P	4
14	H2-0750HN	3/4" NUT, Z/P	4
15	H1-0500-225	1/2" x 2-1/4" BOLT GR.5, Z/P	2
16	H4-0500LW	1/2" SPLIT LOCKWASHER, Z/P	2
		1/8" RUBBER MAT 18"x48"	6



HDWE-MH7

PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BAIRD SUPPORTING SYSTEMS. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BAIRD SUPPORTING SYSTEMS IS PROHIBITED.	 WWW.BAIRDMOUNTS.COM	UNLESS OTHERWISE SPECIFIED:	BAIRD MOUNTING SYSTEMS		DRAWN BY	DATE
		DIMENSIONS ARE IN INCHES	WATERLOO, IA 50703		JK	10/03/18
		TOLERANCES:	PHONE: 319-233-3561		MATERIAL	FINISH
		FRACTIONAL ±	SALES@BAIRDMOUNTS.COM		STEEL	HDG
		ANGULAR: MACH ± BEND ±			DWG. PURPOSE	SHEET
TWO PLACE DECIMAL ±			INST	1	-	
THREE PLACE DECIMAL ±			TITLE:	PART. NO.		
DO NOT SCALE DRAWING			Universal Ridgemount w/Pad	UR-(000)X(0)-R Assembly Instructions		
				DWG. NO.		
				UR-(000)X(0)-R Assembly Instructions		